


Karen control ref.




DC Power Options

9 volt battery (006P) or 9V-18V DC adapter (Negative Tip, 2.1mm x 5.5mm barrel plug) available. "Regulated DC adapters only"

* By unplugging the guitar cable from INPUT JACK, you can preserve battery power.

Gain width trimmer Control ref.

A phillips screwdriver of very small size can be used. Since the trimmer is a very delicate parts, please turn gently.



* When trimmer is at "0", you cannot control the gain.